TELLDUS

YOU WILL NEED




ADD A **Remote Control**

If you have a self-learning 433,92 MHz device already installed and want to use a remote control with it, here's how!







0

Note! This guide is for 433,92 MHz self learning devices only. If you have 433,92 MHz code switch devices and remote you can manually set the code on the remote, please refer to the manual for configuration. If you have a Z-Wave remote control and devices you can control devices by association.



Telldus is marketed by Proove AB, Sweden www.proove.se • +46 (0)346 715600



facebook.com/telldus

@telldus