

Power supply	USB Power Supply, 5V DC
Operation temperature	-10 ~ +40°C
Distance to Z-Wave	up to 30 m indoors (depending on building materials)
Distance to 433Mhz Sensors	up to 100 m (depending on building materials)
Dimensions (WxHxD)	79x16x24mm
Electricity consumption	0,3 W

433MHz Sensors

Battery's	2 x UM-3 or "AA" size 1.5 V
Operation temperature	-10 ~ +60°C
Distance to USB Key	up to 100 m (depending on building materials)
Receiving Cycle	Remote Thermo/Hygro - Sensors cca. 45s Rain Gauge cca. 183s Wind Sensor cca.33s
Temperature Accuracy	+/-1°C or +/-2°F
Humidity Accuracy	+/-5%
Wind Speed Accuracy	+/- (2mph + 5%)
Wind Direction Accuracy	+/-11.25°

Z-Wave Device Class:

ZWAVEPLUS_INFO_REPORT_ROLE_TYPE_SLAVE_AL
WAYS_0N

GENERIC_TYPE_SENSOR_MULTILEVEL

SPECIFIC_TYPE_ROUTING_SENSOR_MULTILEVEL

Z-Wave Supported Command Classes:

COMMAND_CLASS_ZWAVEPLUS_INFO_V2,

COMMAND_CLASS_DEVICE_RESET_LOCALLY_V1

COMMAND_CLASS_MANUFACTURER_SPECIFIC_V2

COMMAND_CLASS_POWERLEVEL_V1

COMMAND_CLASS_SECURITY

COMMAND_CLASS_FIRMWARE_UPDATE_MD_V2

Z-Wave Securely Supported Command Classes:

COMMAND_CLASS_VERSION_V2

COMMAND_CLASS_SENSOR_MULTILEVEL_V7

COMMAND_CLASS_MULTI_CHANNEL_V4

COMMAND_CLASS_ASSOCIATION_V2

COMMAND_CLASS_MULTI_CHANNEL_ASSOCIATION_V3

COMMAND_CLASS_ASSOCIATION_GRP_INFO_V2

COMMAND_CLASS_CONFIGURATION

COMMAND_CLASS_BATTERY

COMMAND_CLASS_MARK

COMMAND_CLASS_BASIC

Endpoint 1, 2, 3, 4, 5, 6, 7, 8, 9, 10

Device Class:

ZWAVEPLUS_INFO_REPORT_ROLE_TYPE_SLAVE_AL
WAYS_0N

GENERIC_TYPE_SENSOR_MULTILEVEL

SPECIFIC_TYPE_ROUTING_SENSOR_MULTILEVEL

Command Classes:

COMMAND_CLASS_ZWAVEPLUS_INFO_V2,

Securely Supported Command Classes:

COMMAND_CLASS_VERSION_V2

COMMAND_CLASS_SENSOR_MULTILEVEL_V7

COMMAND_CLASS_ASSOCIATION_V2

COMMAND_CLASS_MULTI_CHANNEL_ASSOCIATION_V3

COMMAND_CLASS_ASSOCIATION_GRP_INFO_V2

COMMAND_CLASS_BATTERY

COMMAND_CLASS_MARK

COMMAND_CLASS_BASIC

This product can be included and operated in any Z-Wave network with other Z-Wave certified devices from any other manufacturers. All constantly powered nodes in the same network will act as repeaters regardless of the vendor in order to increase reliability of the network.

Remote Weather Sensors

The remote weather sensors include a thermo-hygrometer, anemometer (wind sensor) and rain sensor. All data collected by the sensors are transmitted to the Weather Station Key by wireless RF, with a range up to 100 meters (open area). The Weather station Key supports a maximum of 2 thermo-hygrometers, allowing 2 channels of temperature/humidity display (Ch1 and Ch2).

Setting up the Remote Weather Sensors

Before starting up the Weather Station Key, setup all the remote sensors first.

When placing the sensors, make sure that they are within receiving range of the console unit.

Ideally, they should be within the line of sight of the console unit. Transmission range may be affected by trees, metal structures and electronic appliances. Test reception before permanently mounting your weather station.

Also make sure that the sensors are easily accessible for cleaning and maintenance.

The remote sensors should be cleaned on a weekly basis, since dirt and debris will affect sensor accuracy.

Setting up the Thermo-Hygro Sensor(s)



1. Open the latch at the base of the thermo-hygro sensor.
2. Set the channel with a slide switch to Ch1 or Ch2 (Channel has to be selected before inserting a battery's)
3. Insert two 2 x UM-3 or "AA" size 1.5 V batteries.
4. Use a pin to press the "RESET" key which is in the battery compartment of thermo-hygro sensors after LED flash.
5. Replace the latch and mount the unit at desired location.

Placement Tips:

- The thermo-hygro sensor should be in an area with free air circulation and sheltered from direct sunlight and other extreme weather conditions. Place the unit in a shaded area, such as under a roof.

- Avoid placing the sensor near sources of heat such as chimneys.

- Avoid any areas which collect and radiate heat in the sun, such as metal, brick or concrete structures, paving, patios and decks.

- Ideally, place the sensor above natural surfaces such as a grassy lawn.

- The international standard height for measurements of air temperature is at 1.25m (4 ft) above ground level.

Setting up the Rain Sensor

1. Unlock the funnel-shaped top of the rain sensor by turning both knobs on the sides of the rain sensor in an anti-clockwise direction.

2. Lift the top off the base and insert two 2 x UM-3 or "AA" size 1.5 V batteries into the battery holder.

3. Replace the lid and secure into place by turning the knobs clockwise.

4. Place the rain sensor in a location such that precipitation can fall directly into the sensor, ideally 2-3 ft above the ground. It may be secured into place by using the four screws provided.

5. The sensor must be accurately levelled for optimum performance. To check if the sensor is levelled, remove the lid and check if the ball bearing inside is at the midpoint of the leveller. Additionally, a bubble level or carpenter's level may be used.

6. Attach the protective screen onto the top of the lid. The screen will prevent any debris entering the sensor.

Placement Tips:

- The rain sensor should be placed in an open area away from walls, fences, trees and other coverings which may either reduce the amount of rainfall into the sensor, deflect the entry of wind - blown rain, or create extra precipitation runoff. Trees and rooftops may also be sources of pollen and debris.

- To avoid rain shadow effects, place the sensor at a horizontal distance corresponding to two to four times the height of any nearby obstruction.

- It is important that rain excess can flow freely away from the sensor. Make sure that water does not collect at the base of the unit.

- The rainfall measurement mechanism utilizes a magnet; hence do not place any magnetic objects around the proximity of the sensor.

Setting up the Anemometer (Wind Sensor)

1. Assemble the wind cups and wind vane to the anemometer arm
2. Attach the assembled anemometer to the base.
3. Insert two 2 x UM-3 or "AA" size 1.5 V batteries into the battery holder in the base and connect the second battery to the solar panel connector.
4. Mount the anemometer onto a vertical surface, using the fittings provided.

Placement Tips:

- Check that wind can travel freely around the anemometer and is not distorted by nearby buildings, trees or other structures.

- For better results, place the anemometer at least 3 m above local structures and obstacles. The ground creates a frictional effect to wind flow and will attenuate readings.

- Aim for maximum exposure of the anemometer to the commonest wind directions in your area.

- The official mounting location for anemometers is 10m (33 ft) above ground level in a clear unobstructed location.

Maintenance

Changing Batteries

The battery statuses of the sensors are checked every hour. If the low battery indicators light up, replace the batteries for the corresponding unit immediately.

Changing Batteries for the Remote Sensors

1. Replace the batteries following the setup instructions for the corresponding sensor.

2. When the batteries are properly installed, the sensor will resume sending signals to the main console unit.

Cleaning

The Weather Station Key and outer casings for the remote sensors can be cleaned with a damp cloth. Small parts can be cleaned with a cotton tip or pipe-cleaner.

Never use any abrasive cleaning agents and solvents. Do not immerse any units with electronic parts in water or under running water.

Anemometer

- Check that the wind vane and wind cups can spin freely and are free from dirt, debris or spider webs.

Rain Sensor

Like all rain gauges, the rain sensor is prone to blockages due to its funnel shape. Checking and cleaning the rain sensor from time to time will maintain the accuracy of rain measurements.

- Detach the protective screen and lid. Remove any dirt, leaves or debris by cleaning the items with soapy water and a damp cloth. Clean small holes and parts with a cotton tips or pipe-cleaner.

- Look out for spiders or insects that might have crawled into the funnel.

- Also clean the swinging mechanism with a damp cloth.

Troubleshooting

The Weather Station Key will not receive any data when the wireless link with the Sensor is lost.

Check or replace the batteries for the corresponding sensor.

If the above does not solve the problem, check the wireless transmission path from the corresponding sensor to the main console unit and change their locations if necessary.

Although wireless signals can pass through solid objects and walls, the sensor should ideally be within the line of sight of the console unit.

The following may be the cause of reception problems:

- Distance between remote sensor and Weather Station Key is too long. (Maximum transmission distance in open area conditions is up to 100 m.)

- Signal shielding materials such as metal surfaces, concrete walls or dense vegetation in the path of transmission.

- Interferences from wireless devices (such as cordless phones, radio headsets, baby listening devices) and electronic appliances.

The weather readings do not correlate with measurements from TV, radio or official weather reports

Weather data can vary considerably due to different environmental conditions and placement of weather sensors.

Check the placement tips included in this manual to site your sensors in the best possible way.

PRECAUTIONS

This product is engineered to give you years of satisfactory service if you handle it carefully. Here are a few precautions:

1. Do not immerse the unit in water.

2. Do not clean the unit with abrasive or corrosive materials. They may scratch the plastic parts and corrode the electronic circuit.

3. Do not subject the unit to excessive force, shock, dust, temperature or humidity, which may result in malfunction, shorter electronic life span, damaged battery and distorted parts.

4. Do not tamper with the unit's internal components. Doing so will invalidate the warranty on the unit and may cause unnecessary damage. The unit contains no user-serviceable parts.

5. Only use fresh batteries as specified in the user's manual. Do not mix new and old batteries as the old ones may leak.

6. Always read the user's manual thoroughly before operating the unit.

CAUTION

- The content of this manual is subject to change without further notice.

- Due to printing limitation, the units shown in this manual may differ from the actual units.

- The contents of this manual may not be reproduced without the permission of the manufacturer.

This user manual is subject to change and improvement without notice.

NOTE: User manual is valid for module with SW version S1 (SW version is part of P/N)! Example: P/N: ZMNHZDx HxS1Px

Important disclaimer

Z-Wave wireless communication is inherently not always 100% reliable, and as such, this product should not be used in situations in which life and/or valuables are solely dependent on its function.

As well, Weather Station Sensors can lose communication with the Weather Station Key. The caution should be taken when using the data from the sensors for controlling other devices using scenarios or associations.

Warning!

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new once, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not in-stalled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/ TV technician for help.



Qubino

Goap d.o.o. Nova Gorica
Ulica Klementa Juga 007
5250 Solkan
Slovenia



E-mail: info@qubino.com
Tel: +386 5 335 95 00
Web: www.qubino.com

Date: 18.10.2016
Document: Qubino_Weather Station
user manual_V1.2_eng